

## Self-assembly instruction for flat cargo mat.

**Necessary tools:** lever, wheel spanner, wheel locking chocks, screwdriver, set of spanners or open-ended spanners.

**⚠ Caution:** Before attempting to install the flat cargo mat, make sure to wear protective goggles and gloves. Work safety rules and caution should be maintained during assembly operations due to the need to use workshop tools and assembly components.

**⚠ Attention!** Before the installation, the carpet should be laid out on a flat surface in a place not exposed to direct sunlight, in a room where the temperature is close to room temperature.

### **Step one: place the vehicle in a safe location and secure it to prevent any possibility of movement during the operation**

The best place to set up your vehicle for the installation of the cargo mat in your car is the garage, the driveway in front of the garage or other safe place.

Once the vehicle is placed, the handbrake must be pulled and first gear must be engaged. On automatic transmissions, place the jack in position P. In addition, support the rear wheels on both sides. It is best to use special chocks for this.

### **Step two: install the cargo mat**

Before installing the cargo mat, first match the carpet to the floor in the load compartment of the vehicle. If required, remove the plastic grilles, the thresholds at the rear and side doors and the fasteners for the load securing straps during transport.

Next, lay down the cargo mat on the floor of the vehicle's load compartment. Attach all previously removed elements.

If the car has a factory installed plywood floor, attach the cargo mat to it using a screwdriver and metal screws.

**⚠ Caution:** The fastening of the cargo mat should be stable and there should be no uncontrolled movement of the cargo mat.

### **Step three: Finish the installation of the cargo mat.**

Remove all previously applied protection of the car and prepare it for safe usage.