

SKODA OCTAVIA I (1U2)				
Model / typ	Pojemność	Moc Kw (PS)	Rok produkcji	Kod silnika
SKODA OCTAVIA I (1U2) 1.4 liftback	1397	44 (60)	1999.04 - 2001.03	AMD
SKODA OCTAVIA I (1U2) 1.4 16V liftback	1390	55 (75)	2000.09 - 2010.12	AXP, BCA
SKODA OCTAVIA I (1U2) 1.6 liftback	1595	75 (102)	2000.11 - 2010.12	AVU, BFQ
SKODA OCTAVIA I (1U2) 1.6 liftback	1598	55 (75)	1996.09 - 2004.09	AEE
SKODA OCTAVIA I (1U2) 1.6 liftback	1595	74 (101)	1997.02 - 2007.12	AEH, AKL
SKODA OCTAVIA I (1U2) 1.8 liftback	1781	92 (125)	1996.09 - 2000.07	AGN
				AGU, ARX, AUM,
SKODA OCTAVIA I (1U2) 1.8 T liftback	1781	110 (150)	1997.08 - 2010.12	ARZ
SKODA OCTAVIA I (1U2) 1.8 T 4x4 liftback	1781	110 (150)	2001.05 - 2006.05	ARX
SKODA OCTAVIA I (1U2) 1.9 SDI liftback	1896	50 (68)	1997.06 - 2003.12	AGP, AQM
SKODA OCTAVIA I (1U2) 1.9 TDI liftback	1896	74 (100)	2005.10 - 2010.12	AXR
SKODA OCTAVIA I (1U2) 1.9 TDI liftback	1896	96 (130)	2002.09 - 2004.09	ASZ
SKODA OCTAVIA I (1U2) 1.9 TDI liftback	1896	66 (90)	1996.09 - 2010.03	AGR, ALH
SKODA OCTAVIA I (1U2) 1.9 TDI liftback	1896	81 (110)	1997.08 - 2006.01	AHF, ASV
				AEG, AZJ, AZH,
SKODA OCTAVIA I (1U2) 2.0 liftback	1984	85 (116)	1999.04 - 2007.05	AQY, APK
SKODA OCTAVIA I (1U2) RS 1.8 T liftback	1781	132 (180)	2001.05 - 2006.01	AUQ

SKODA OCTAVIA I Combi (1U5)				
Model / typ	Pojemność	Moc Kw (PS)	Rok produkcji	Kod silnika
SKODA OCTAVIA I Combi (1U5) 1.4 16V Kombi	1390	55 (75)	2000.08 - 2010.12	AXP, BCA
SKODA OCTAVIA I Combi (1U5) 1.6 Kombi	1598	55 (75)	1998.07 - 2004.09	AEE
SKODA OCTAVIA I Combi (1U5) 1.6 Kombi	1595	74 (101)	1998.07 - 2007.12	AEH, AKL
SKODA OCTAVIA I Combi (1U5) 1.6 Kombi	1595	75 (102)	2000.09 - 2010.12	AVU, BFQ
SKODA OCTAVIA I Combi (1U5) 1.8 20V Kombi	1781	92 (125)	1998.07 - 2000.07	AGN
				AGU, ARX, AUM,
SKODA OCTAVIA I Combi (1U5) 1.8 T Kombi	1781	110 (150)	1998.07 - 2010.12	ARZ
SKODA OCTAVIA I Combi (1U5) 1.8 T 4x4 Kombi	1781	110 (150)	2001.05 - 2006.05	ARX
SKODA OCTAVIA I Combi (1U5) 1.9 SDI Kombi	1896	50 (68)	1998.07 - 2003.12	AGP, AQM
SKODA OCTAVIA I Combi (1U5) 1.9 TDI Kombi	1896	81 (110)	1998.07 - 2006.01	AHF, ASV
SKODA OCTAVIA I Combi (1U5) 1.9 TDI Kombi	1896	74 (100)	2000.08 - 2010.12	AXR
SKODA OCTAVIA I Combi (1U5) 1.9 TDI Kombi	1896	66 (90)	1998.07 - 2010.03	AGR, ALH
SKODA OCTAVIA I Combi (1U5) 1.9 TDI Kombi	1896	96 (130)	2002.09 - 2004.09	ASZ
SKODA OCTAVIA I Combi (1U5) 1.9 TDI 4x4 Kombi	1896	66 (90)	1999.11 - 2006.02	AGR
SKODA OCTAVIA I Combi (1U5) 1.9 TDI 4x4 Kombi	1896	74 (100)	2000.09 - 2006.01	ATD
				AEG, AZJ, AZH,
SKODA OCTAVIA I Combi (1U5) 2.0 Kombi	1984	85 (116)	1999.04 - 2007.05	AQY, APK
SKODA OCTAVIA I Combi (1U5) 2.0 4x4 Kombi	1984	85 (116)	2000.08 - 2004.09	AZJ, AZH
SKODA OCTAVIA I Combi (1U5) 2.0 4x4 Kombi	1984	88 (120)	2000.01 - 2010.12	ATF
SKODA OCTAVIA I Combi (1U5) RS 1.8 T Kombi	1781	132 (180)	2002.08 - 2006.01	AUQ
SKODA OCTAVIA I nadwozie zamknięte / kombi (1U5) 1.9 D nadwozie zamknięte / kombi	1896	50 (68)	2000.08 - 2003.12	AQM
SKODA OCTAVIA I nadwozie zamknięte / kombi (1U5) 1.9 TDI nadwozie zamknięte / kombi	1896	66 (90)	2000.08 - 2010.03	ALH