

Self-assembly instructions for the bottom engine cover.

The bottom engine cover can be assembled using a channel in the garage or a workshop jack.

Necessary tools: lever, wheel spanner, wheel locking chocks, screwdriver, set of spanners or open-ended spanners.

⚠ Caution: Before attempting to assemble the engine cover, make sure to wear protective goggles and gloves. It is also recommended to put on protective clothing. Work safety rules and caution should be maintained during assembly operations due to the need to use workshop tools and assembly components.

Step one: place the vehicle in the relevant installation space and ensure that it is securely positioned to prevent any movement during the installation work.

The best place to set the vehicle up for bottom engine cover installation is a garage with a channel or workshop lift.

Once the vehicle is positioned over a garage channel, pull the handbrake and put it into first gear. For automatic transmissions, place the jack in position P. Additionally, support the rear wheels on both sides. It is best to use special chocks for this.

When using a workshop lift, follow the manufacturer's operating instructions.

⚠ Caution: Once the car is ready for the installation of the bottom engine cover, make sure that the engine compartment is completely cool. It is recommended that you wait about 15 minutes for the engine compartment to properly cool down.

Step two: install the bottom engine cover

Place and position the bottom engine cover in the location intended for its installation. Once in place, use a screwdriver or spanners, flat-head screwdrivers or assembly parts to fasten the engine cover, using the mounting holes provided in the cover, to the factory mounting points in the vehicle body, plastic bumpers, the internal structure of the engine compartment of the car and the wheel arches. Once again, check that the bottom engine cover is properly installed.

⚠ Caution: The installation of the cover should be stable and there should be no uncontrolled movement of the cover.

Step three: finish the installation of the bottom engine cover.

If the garage channel was used to install the cover, remove all previously applied protection of the car and prepare it for safe usage.

If a workshop lift was used, follow the manufacturer's operating instructions.